

CI/SfB	(29)	Yt4	(k2)
CAW P10			
Uniclass JP10:L68114			
June 2010 - Provisional			

S707-90

Waterborne Basecoat

Description

S707-90 Waterborne Basecoat is a pale blue thin film intumescent coating for the fire protection of internal structural steelwork. S707-90 can provide up to 120 minutes fire resistance.

Application Check List

The following instructions are for on-site application only. For off-site application, refer to Nullifire.

Ensure that:

- The primer is compatible with S707-90 and has been applied correctly.
- The overcoating period for the primer has not been exceeded.
- The correct primer is used for galvanised steel.
- All damage to the primer has been repaired & re-primed.
- Site and weather conditions are within specification.
- S707-90 is stored correctly.
- Surface is clean, dry and free from contamination.
- Correct spray equipment is available, if appropriate.
- Application instructions have been read prior to commencement of work.
- Ensure different basecoats are not applied on the same section of steel.
- Equipment should be clean and free from contaminants or dried material.
- Wet film gauges are available for use.

Availability

Direct from Nullifire (see back of leaflet for address and telephone details).

USAGE GUIDELINES

Surface Preparation

S707-90 should be applied onto a clean, undamaged, dry and primed steel surface.

Certain types of primers can cause adhesion problems and should be avoided. These include:

- Chlorinated rubbers
- Bitumen
- Thermoplastic primers

Nullifire have carried out compatibility testing on a wide range of primers and can

be contacted on +44 (0) 24 7685 5000 for confirmation of compatibility with S707-90.

Galvanised surfaces should be prepared by an application of T-wash or mordant solution followed by a compatible non-saponifiable primer. The primer should be applied in accordance with the manufacturer's instructions.

If a zinc rich primer is used, it is advisable to seal this with a suitable tie coat or travel coat prior to shipment to site. If the steel is left exposed to the atmosphere with just a zinc rich primer, surface salts may build up on the steel. These salts, if not adequately removed, may cause adhesion problems for any subsequent coating applied. Removal of the salts can be achieved by high-pressure washing. If adequate removal of the salts cannot be guaranteed, a suitable tie coat may have to be applied prior to the application of the S707-90 Waterborne Basecoat.

Nullifire should be consulted for technical advice when zinc rich primers or the overcoating of existing paints are specified for use.

Product Specification

Specific Gravity: 1.40
 Volume Solids: 69% ± 3%
 VOC: 30 g/litre
 Theoretical Coverage: 1.45 litres/m² @ 1.0 mm DFT
 Note: The volume solids content of this material has been measured in accordance with the method laid down in ISO 3233: 1998.

Site Conditions During Application

Nullifire S707-90 is recommended for application and use on dry protected structural steel only. If the basecoat is allowed to get wet, it is likely to be damaged – blistering and wrinkling may occur.

S707-90 should only be applied when the air and steel temperatures are above 5°C. Relative humidity should be below 80% for successful application. Steel surface temperature should be a minimum of 3°C above the dew point. Ensure the steel is dry and free from contact with rain or condensation during the application and drying of S707-90.

Application Methods

S707-90 is supplied ready for use and must not be thinned but should be thoroughly mechanically stirred prior to use.

AIRLESS SPRAYING

S707-90 may be applied up to a maximum wet film thickness (WFT) of 1.2 mm in a single spray coat comprising of several quick passes. Achieving maximum loadings will depend on site conditions.

Build up thickness to achieve loading required in several quick passes. It may be possible to apply two coats of S707-90 in one day particularly if the atmospheric temperature is above 20°C and relative humidity below 70%. However, before doing this, ensure that the previously applied coat is dry, particularly in the web/flange junctions.

Airless spray equipment is recommended and should match these guidelines:

Operating Pressure: 2500 – 3000 psi (175 - 210 kg/cm²)
 Tip Size: 17 – 21 thou
 Fan Angle: 20° – 40°
 Hose Diameter: 10 mm (3/8") (Internal Diameter)
 Hose Length: Max. 60 metres

BRUSH/ROLLER APPLICATION

For brush application use a "laying on" technique to avoid heavy brush marking.

Maximum wet film per coat when applied using a brush or roller is 0.6 mm. A short piled roller will produce a light textured finish.

Thickness Requirements

During application, measure the wet film thickness frequently with the WFT gauge provided to ensure the correct thickness is being applied.

To use the gauge, insert the teeth into the wet basecoat. The last tooth to be coated indicates the wet film thickness achieved.

In the event of over or under applications, adjustments to the loading rates of subsequent coats will be required.



S707-90

Nullifire - a brand of Tremco illbruck Coatings Ltd
Torrington Avenue
Coventry, West Midlands CV4 9TJ
Tel: 02476 855000
Fax: 02476 469547
Email: protect@nullifire.com
Website: www.nullifire.co.uk

Drying Times

Drying of S707-90 is dependent upon a number of factors including:

- Temperature
- Air movement
- Humidity
- Method of Application
- Thickness of coating

High humidity and low air movement or low steel temperatures can result in condensation on the steelwork causing prolonged drying times and possibly poor basecoat adhesion.

Recoat Times (in hours)

Indications of recoat or topsealing times taking into account loading areas and application methods are given below:

- Hours per application (0.6 mm wft) – Thin coat
- Hours per application (0.8 mm wft) – Medium coat
- Hours per application (1.2 mm wft) – Thick coat

R/H	Spray	10°C		20°C		30°C	
		Still Air	Air Flow	Still Air	Air Flow	Still Air	Air Flow
30%	Thin	3 hours	2.5 hours	4 - 5 hours	1.5 hours	3 - 4 hours	1.5 hours
	Medium	6 hours	3.5 hours	6 hours	3 hours	4 - 5 hours	2.5 hours
	Thick	12 hours	4.5 hours	8 hours	3.5 hours	6 hours	3 hours
50%	Thin	10 hours	3 hours	6 hours	2.5 hours	5 hours	1.5 hours
	Medium	12 hours	4 - 5 hours	8 hours	3.5 hours	6 hours	3 hours
	Thick	18 hours	6 hours	12 hours	4.5 hours	10 hours	3.5 hours
70%	Thin	12 hours	6 hours	10 hours	4.5 hours	8 hours	3 hours
	Medium	18 hours	9 hours	12 hours	6.5 hours	10 hours	6 hours
	Thick	24 hours	12 hours	18 hours	9 hours	12 hours	7 hours

- Brushing or rolling adds about 20% to drying time (compared to spraying).
- Drying times are doubled at 5°C or at over 75% relative humidity.
- Final drying time before topsealing is a minimum of 16 hours.
- These figures are based on constant conditions, fluctuations up or down will give variations to the drying time. If overnight condensation causes wetting a further full drying period should be allowed.

Final Thickness Check

Take dry film thickness (DFT) readings as soon as the coating is sufficiently hard to allow a reading to be made without indenting the surface.

DFT's may be taken using equipment such as an electronic electromagnetic type PosiTector 6000 Gauge.

Ensure that the DFT of the primer is deducted from the reading of the basecoat.

Do not apply topseal until the readings are in accordance with the specified thicknesses.

Application of Topseal

Once DFT's have been achieved as specified, TS816WAC Topseal (waterborne) for internal applications, TS815SAC Topseal (solventborne) or TS818WPU (waterborne 2K) for temporary exposure. Ensure the S707-90 is completely dry before applying Topseal.

Maintenance

Damaged areas should be abraded back to a sound surface. The surface should then be clean and dry before re-applying. System S Filler may be used for repairing scratches and chips. Once repaired topseal should be re-applied. Refer to Nullifire System S Maintenance Instructions.

Storage

S707-90 should be stored internally between 5°C and 30°C. Do not store below 5°C. At temperatures above 25°C, the shelf life will be reduced. Shelf life is normally 6 months in sealed containers.

To Order

In the U.K., S707-90 Basecoat can be ordered directly from Nullifire, Coventry on +44 (0) 24 7685 5000.

In other countries, S707-90 Basecoat can be purchased through a network of Distributors, details of which can be obtained from Nullifire or from our Web site on <http://www.nullifire.com>.

Health & Safety Precautions

Please refer to H and S Data Sheet Ref: S707-90 MSDS date: 2009.

Technical Service

Nullifire has a team of experienced Technical Sales Representatives who provide assistance in the selection and specification of products. For more detailed information, service and advice, please call Customer Services on 02476 855000.

Guarantee / Warranty

This information is offered in good faith but without guarantee or liability. In cases of doubt, users should consult with relevant authority.

Information given herein is supplied for your guidance only and is based upon the results of controlled tests and experience obtained in the application of the product referred to by Nullifire.

As the supplier only, Nullifire has no control over the method or conditions of application of the product and consequently no warranties expressed or implied are intended to be given as to the coverage or performance of the products mentioned or referred to herein and no liability will be excepted for any loss, damage or physical injury resulting from the use or application of the information, data or products mentioned or referred to herein.